



TV-KANALEN & FREQUENTIE VS. SHURE FREQUENTIE CODES PER TYPE

TV-CH.	FREQUENCY		VHF			UHF					
	Europe !!	van MHz tot MHz	T	LX	SC	UT	ULX	U MK1	U MK2	PSM400	PSM700
8			NX,NY,NZ,PU	NX,NY,NZ,PU	DE,DF,CS,CP						
55	744	752					Q2 748				
56	752	760					Q2				
57	760	766					Q2				
58	766	774					Q2				
59	774	782				VA,VB,VC,VD	Q2	MC			
60	782	790					Q2/R4 784		R4		
61	790	798					R4		R4		
62	798	806					R4	MB 800	R4	MN 800	MN 800
63	806	814				TN,TP,TR,TS	R4	MB	R4	MN	MN
64	814	822					R4	MB	R4	MN	MN
65	822	830					S3 829	MB		MN	MN
66	830	838					S3				
67	838	846					S3			KE 842	KE 842
68	846	854					S3			KE	KE
69	854	862					S3			KE	
70	862	870				VU,VW,VX	S3 865			KE 865	KE 865